

Cobra XL by **CSC** TRIKES

Spoiler Installation Instructions

1. Carefully place the fiberglass template on the fender as shown.

Template with 3 holes Right side.



Template with 2 holes Left side.



2. Mark the five holes to be drilled with a marker or wax pen. Do not drill through the template.
3. Remove the template and drill five 5/16 holes in the fender.

Caution as you will be drilling into the trunk area and through your carpet.

4. Route the Wing harness up to the center hole on the right side.
5. Using the wing plug as a template insert the 2 wire pins into the provided connector.
6. Use a small amount of silicone sealant around each hole.

7. Plug in the wing to the Harness and keep the plug above the body.
8. Install the Wing by lowering it into all 4 of the holes.
9. Secure with flat washers and Flange nuts.
10. Route the wire harness down to the license plate light plug.
11. Unplug the license plate light plug and plug in the T harness from the wing.
12. Reinstall any carpet with 3 M spray adhesive.
13. Wing will now function as a running and brake light.

**FROM ALL OF US AT CALIFORNIA SIDECAR.
ENJOY THE RIDE.**